# **Rail Vehicle Suspensions and Components**

Dr. Elton Toma, P.Eng. National Research Council Canada

June 22, 2022





National Research Council Canada



1

# **Overview**

- **Rail Car Types.** ullet
- Rail Car Suspensions: Why are suspensions important; reasons ulletfor suspension design choices; freight vs. passenger designs.
- Rail Car Components.



PRINCIPLES COURSE · JUNE 22



National Research Council Canada

# **Freight Car Types**

- Industry started simple: only a few car types carried • everything.
- As builders and railroads looked for efficiencies, new car types were developed.






National Research Council Canada

#### **Freight Car Types**



https://www.trinityrail.com/productdetails.aspx?id=121&catid=24

https://www.trinityrail.com/productdetails.aspx?ID=55&catid=31



- reduce damage to • goods,
- speed up • loading/unloading,
- lower overall costs!





https://www.trinityrail.com/productdetails.aspx?id=13&catid=29 https://www.trinityrail.com/productdetails.aspx?id=39&catid=30





National Research Council Canada


### **Freight Car Types**



https://www.steelcar.com/products/25500g-tank-car



https://www.steelcar.com/products/centerbeam



https://www.gbrx.com/media/2352/gbx-tech-sheet-stack- https://www.gbrx.com/media/1447/flat89.pdf 5-unit-maxi-stack-v.pdf



What is common between all these different cars:

- They operate empty ۰ and loaded.
- The car bodies all sit • on top of freight trucks.





National Research Council Canada



## **Passenger Car**







**Possibly even greater variety!** 

- Often custom or "one-off" designs, unique to a city or a route within a city.
- Urban and intercity; streetcars to complete trainsets.
- Light to heavy; low speed to very fast.



# **Car Types**

- Light weight (LW): weight of the empty car.
  - ~40,000 pounds to over 100,000 pounds (autorack).
- Load Limit (LD LMT): what the commodity weighs.
- Gross Rail Load (GRL): maximum loaded weight.
  - 263,000 to 286,000 pounds...
  - or lower! Depends on commodity (density): eg. autorack GRL of ~ 200,000 pounds.



# **Car Types**

- **GRL to LW ratio** 
  - Passenger: ~1.5 to 2
  - Autorack: ~ 1.8 to 2
  - 5-pack container: ~4
  - Ore car: ~5.5 to 6

- Car, pickup truck: ~ 1.2 to 1.4 •
- Cat 797 mining truck: ~2.5 •



How do rail cars handle this difference between empty and loaded weights?




PRINCIPLES COURSE · JUNE 22



National Research Council Canada

#### **Freight Car Trucks**







National Research Council Canada

### **Freight Car Trucks**



PRINCIPLES COURSE · JUNE 22



National Research Council Canada

#### **Passenger Car Truck**



https://www.mobility.siemens.com/mobility/global/SiteCollectionDocuments/en/rail-solutions/components-and-systems/bogies-catalog-en.pdf





National Research Council Canada

# **Rail Car Suspensions**

#### Why is there a suspension?

- 1. Load equalization: transfer the car load evenly to the rails.
- 2. Vibration Isolation: Passenger comfort, prevent damage to goods and to the car itself.
- 3. Control vehicle motion: Traction, braking, lateral curving forces, dynamic stability.



### Load Equalization

- 1. Transfer the car load evenly to the rails.
- 2. A car with no suspension would lift wheels on even slightly uneven track, such as when entering curves.
- 3. Rail and subgrade designs place a limit on the maximum wheel load on the rail.



PRINCIPLES COURSE · JUNE 22




National Research Council Canada



13

# **Load Equalization**

- The truck balances the load between • the front and rear wheels by pivoting at the bolster.
- The wheel load is always equally split! •
- Not as effective at higher speeds... •



walking beam suspension



PRINCIPLES COURSE · JUNE 22



National Research Council Canada



## **Load Equalization**

- Passenger car truck frames are usually rigid frames. A primary and a secondary suspension aids in balancing the wheel loads.
- Locomotive trucks have powered axles. To maximize lacksquaretraction the vertical loads must be balanced, so a primary and a secondary suspension is used on freight locomotive trucks.





National Research Council Canada

# **Primary and Secondary Suspension**

- Primary Suspension: A suspension at a wheel location, between a 1. wheelset and the truck frame.
- Secondary Suspension: A suspension between a car body and a 2. truck frame.







National Research Council Canada




# **Primary and Secondary Suspension**



# **Primary and Secondary Suspension**



#### **Passenger Car Truck**





Secondary springs

https://www.mobility.siemens.com/mobility/global/SiteCollectionDocuments/en/rail-solutions/components-and-systems/bogies-catalog-en.pdf





National Research Council Canada

Conseil national de recherches Canada WRI 2022

Damper

### **Vibration Isolation**

- As car speeds increase, vibration isolation becomes important – the suspension isolates the car from the changing forces of the wheels on the rails.
- 2. The car and the suspension form a spring-mass system.
- 3. A car with no suspension would move up-down with every undulation on the track. A suspension allows the wheels to "follow" the rails, but keeps the body "isolated".




PRINCIPLES COURSE · JUNE 22



National Research Council Canada

# **Spring-Mass-Damper System**







National Research Council Canada

# **Spring-Mass-Damper System**

- For rail cars
  - Main mass: car body
  - Secondary Suspension: between the car body and the truck
  - Primary Suspension: between the wheelset and the truck

Car Body *"Quarter Car* Model" with Primary and Secondary **Suspension** k<sub>s</sub> Cs Truck k\_ CD






National Research Council Canada

#### **Vibration Isolation**

#### **Spring-mass-damper** systems have well understood properties:

- **Resonance frequency.**
- Damping has an effect on the system response.








National Research Council Canada

# **Spring-Mass-Damper System**

- 1. At the resonance frequency, the mass moves at a very high displacement.
  - This can be controlled with damping.
- 2. Above resonance, the mass is isolated from the vibrations applied to the spring.
- 3. Less damping = high displacement at resonance.
- 4. More damping = less isolation!



#### **Vibration Isolation**



# Springs

- Freight typically use coil springs.
  Passenger; coil or air.
- Freight car "spring groups" are designed to keep the freight car suspension effective when the car is empty and loaded.
  - Concentric springs with different heights.
  - Built up in groups to achieve desired empty and loaded stiffness.
  - Keep empty and loaded resonance low enough.
    - National Research Conseil Council Canada recherch

Conseil national de recherches Canada WRI 2022

DOODLE SIDE SI KING DESIGN			
	S-2-A	S-2-B	S-2-C
SPRING TRAVEL	2 1/2"	3 1/16"	3 11/16"
FREE HEIGHT (CENTER GROUP)	9 1/16"	9 5/8"	10 1/4" (OUTER COIL)
SOLID HEIGHT	6 9/16"	6 9/16"	6 9/16"
6" X 11" BEARING SIZE		OOO OOO TOUTERS D-4	
220,000 LBS. MAX RAIL LOAD	4 INNERS D-3 2 OUTER SIDE B-421 2 INNER SIDE B-422	2 INNERS D-4 2 OUTER SIDE B-432 2 INNER SIDE B-433	7 OUTERS D-5 3 INNERS D-5 2 OUTER SIDE B-432 2 INNER SIDE B-433
*WEIGHT PER CAR SET 4 – GROUP (LBS)	549	622	639
SOLID CAPACITY (LBS)	83,865	84,124	83,836
6 1/2" X 12" BEARING SIZE			
263,000 LBS. MAX RAIL LOAD	2 INNERS D-3 2 OUTER SIDE B-421 2 INNER SIDE B-422	6 INNERS D-4 2 OUTER SIDE B-432 2 INNER SIDE B-433	6 INNERS D-5 2 OUTER SIDE B-432 2 INNER SIDE B-433
*WEIGHT PER CAR SET 4 – GROUP (LBS)	657	746	732
SOLID CAPACITY (LBS)	96,709	97,856	96,448
6 1/2" X 12" BEARING SIZE 286,000 LBS. MAX RAIL LOAD			000 000 7 OUTERS D-5 7 INNERS D-6 2 NINEH INNER D-6A 2 SIDE OUTER B-422 2 SIDE OUTER B-423
*WEIGHT PER CAR SET 4 – GROUP (LBS)			797
SOLID CAPACITY (LBS)			107,129
7" X 12" BEARING SIZE 315,000 LBS. MAX RAIL LOAD	8 OUTERS D-3 6 INNERS D-3 2 OUTER SIDE B-421 2 INNER SIDE B-422	0000 0000 8 OUTERS D-4 8 INNERS D-4 2 OUTER SIDE B-432 2 INNER SIDE B-434	COO COO B OUTERS D-5 B INNERS D-6 2 OUTER SIDE B-432 2 INNER SIDE B-432
*WEIGHT PER CAR SET 4 – GROUP (LBS)	866	888-LG	904
SOLID CAPACITY (LBS)	119,000	113,080	116,336


DOUBLE SIDE SPRING DESIGN



PRINCIPLES COURSE · JUNE 22



# Springs





https://www.railwaytechnology.com/contractors/bogies/amsted-rail/

Piece-wise-linear spring rate: lower spring rate when empty, higher spring rate when loaded.



# **Air Springs**




FIGURE 3.11 Schematic showing the operation of a typical air suspension: (a) Equilibrium position; (b) Upstroke; (c) Downstroke.

Handbook of Railway Vehicle Dynamics. Iwnicki, 2006, CRC Press

- Contained gas can act as a spring, but with interesting properties!
- The stiffness is a function of the volume of contained gas, and the change in volume
- Often used on passenger and light rail cars: empty and loaded stiffness can be adjusted






National Research Council Canada

#### **Air Springs**





https://www.bridgestoneindustrial.eu/downloads/Air-Spring-EN.pdf





National Research Council Canada



# **Air Springs**

- Air Springs have some interesting properties: ۲
  - Pre-loading the system allows for constant ride height and • load leveling.
  - Suspension stations can be connected and interact: •
    - Automated levelling; roll in curves.
    - Reduced pitch and roll response.





National Research Council Canada





- What is "Damping"?
  - Energy loss in the system, through friction.
  - In an automobile, typically an oil-filled "shock absorber"
    - Pushing the oil through a hole involves friction
  - But any form of friction works metal-on-metal sliding can be used as a form of damping



PRINCIPLES COURSE · JUNE 22



National Research Council Canada



31

# Damping

- Freight rail cars:
  - Almost universally use surface friction for damping
  - "Friction Wedges" in the truck design.
- Passenger rail cars:
  - Hydraulic is often used.





National Research Council Canada Conseil national de recherches Canada WRI 2022

32

# **Friction Wedges**

- Main form of damping in freight cars.
  - Vertical, but also lateral.
- Wedges are also key in keeping the truck square and stiff.
  - a requirement for high speed performance and better wheel life.





National Research Council Canada



### **Freight Truck Friction Wedges**










National Research Council Canada

#### **Freight Truck Friction Wedges**






PRINCIPLES COURSE · JUNE 22



National Research Council Canada


#### **Friction Wedges**



Experimental study of stick-slip dynamics in a friction wedge damper. N.K. Chandiramani, K. Srinivasan, J. Nagendra. Journal of Sound and Vibration 291 (2006) 1–18



### **Friction Wedges**



Phil. Trans. R. Soc. A (2008) 366, 747–765 doi:10.1098/rsta.2007.2125 Published online 18 October 2007







National Research Council Canada

### **Friction Dampers**

Chrysler truck design (1950s) - not current but a very interesting design! External "friction snubber" is friction based, not hydraulic.





https://www.allpar.com/corporate/railroads.html

https://www.allpar.com/corporate/railroads.html





National Research Council Canada




## **Hydraulic Dampers**

- Force is proportional to velocity.
- Design details can be adjusted to result in non-linear response to velocity, "blow off" force limits, and other useful design features.



# Freight Truck Curving



http://the-contact-patch.com/book/rail/r0415-curving

- How do you get solid axle wheelsets, mounted to a truck frame, to go around a curve?
- The truck frame must allow some relative motion ۲ of the wheelsets, either with controlled stiffness, or clearances.
- Side effect of being able to negotiate curves is ۲ that lateral stability is affected.
- At high speeds the truck may begin "hunting".





National Research Council Canada

- Systems often have regions of operation that are 'unstable' – e.g. the wobbly shopping cart wheel.
- Aircraft, motorcycles, cars: all have design elements to maintain stability.
- Rail cars have the same limitations with stability and speed.





National Research Council Canada

- The hunting problem was so important, that in the 1950s a competition was held to find a solution.
  - de Possel, Boutefoy, and Matsudaira (1960) described and analyzed the problem.
  - similarities to aero-elasticity problems in high speed aircraft.



Bv ナダテ (Nadate) - Own work. CC BY 3.0. https://commons.wikimedia.org/w/index.php?curid=5161741






National Research Council Canada

- $2b_3$ 2b<sub>2</sub> 2b K., C.  $2L_2$ 21 -D-F (a) 5 2b (b Fig. 1. Two-axle truck model
- Journal of Sound and Vibration 282 (2005) 881-898, Hunting stability analysis of high-speed railway vehicle trucks on tangent tracks. Sen-Yung Lee, Yung-Chang Cheng

Solution: Control lateral and • longitudinal stiffness of the axle-truck system => control hunting.



Multibody System Dynamics, July 2015, Volume 34, Issue 3, pp 259–274, Kinematic oscillations of railway wheelsets. Mate Antali, Gabor Stepan, S. John Hogan





National Research Council Canada

- Freight Car Trucks:
  - Wedge designs to improve warp stiffness.
  - Constant-contact side bearings to provide damping.
  - Bearing adapter inserts: elastomeric pads to control longitudinal and lateral stiffness, improve curving performance.
  - Special truck designs.





Constant contact side bearing



https://www.amstedrail.com /sites/default/files/salescollateral-files/fieldinspection-pocket-guide.pdf



**Bearing adapter: Adapter Plus Steering Pad System** 



PRINCIPLES COURSE · JUNE 22



National Research Council Canada



- Passenger Car Trucks: Primary suspension elements are designed with controlled lateral and longitudinal stiffness values, to allow for steering in curves but also to control hunting at high speeds.
- Lateral dampers and car body-bolster side bearings may also be incorporated.





National Research Council Canada

# **Suspensions for Freight Cars**

- Each car type will have a truck design, spring group, friction wedge design, and side bearing each selected to be optimized for that particular car.
  - Optimal curving performance; low drag, low wheel wear.
  - Prevent hunting when empty (and loaded).
  - Traverse demanding track conditions, switches, crossovers,
  - Cost effective to operate and maintain from a system-wide standpoint.



## **Suspensions for Passenger Cars**

- Each passenger car design will have a truck design with primary and secondary suspension spring and dampers selected to be optimized for that particular car.
  - Optimal curving performance; low drag, low wheel wear.
  - Prevent hunting at all operational speeds.
  - Isolate passengers from vibrations.
  - Traverse demanding track conditions, switches, crossovers.





National Research Council Canada Conseil national de recherches Canada WRI 2022

48

#### **Thank You**





National Research Council Canada